

# JOB SAFETY ANALYSIS



<b>Activity Name:</b> Slump of Freshly Mixed Concrete		<b>Activity Number:</b> ASTM C-143	
<b>Activity Description &amp; Purpose:</b> Measure the slump of freshly mix concrete			
<b>Date Prepared:</b> July 22, 2009		<b>PPE Required</b>	
<b>Typical Equipment</b>		<b>Typical Crew Size:</b>	<b>Typical Material</b>
Description	Class Code	(Crew sizes may vary due to different conditions throughout the state).	Description      Class Code
See Associated Test Procedure		1	See Associated Test Procedure
			Safety Glasses Hard Hat Hard Toe Boots Gloves
<b>Sequence of Job Tasks</b>	<b>Potential Hazards</b>	<b>Safe Job Procedures</b>	
		<b>Never</b>	
1. Filling the mold	1. Concrete splatter causing chemical burns on skin or eyes 2. Struck by mobile equipment (Field testing)	1. Wear required personal protective equipment (Safety glasses and gloves) 2. Maintain an awareness of your surroundings	
		Lift with your back	
2. Lifting of the mold			
3. Measure displacement			
<b>Notes and Specifications Instructions</b>		<b>Other Related Resources</b>	

